



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

Wheel Clearance Template Corvette C5 and C6 front Competition brake package, Sprint spec Essex package no. 13.01.10007 13.01.10008	essex parts services, inc. www.essexparts.com	
	DWG. NO. 1380	REV