



**Instructions:**

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

<b>Wheel Clearance Template</b> Corvette C5/C6 Rear Radi-CAL Competition Package CP9449 caliper, 340 mm disc	<b>essex parts services, inc.</b> <a href="http://www.essexparts.com">www.essexparts.com</a>	
	Essex package numbers: 13.01.10058 - C5; 13.01.10059 - C6	DWG. NO. <b>1638</b>