



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

| | | |
|--|---|----------------------------|
| Wheel Clearance Template Corvette C7 Rear Radi-CAL Competition Package CP9450 caliper, 365 mm disc | essex parts services, inc. www.essexparts.com | |
| | Essex package no. 13.01.10049 | DWG. NO. 1610 REV |