



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

Wheel Clearance Template

Corvette C7 front Radi-CAL
Competition Package
CP9668 caliper, 355 mm disc

Essex package no. 13.01.10033

essex parts
services, inc.
www.essexparts.com

DWG. NO. 1548 REV

5

4

3

2

1