

## **Instructions:**

Print out and confirm the scale (150 mm / 5.91in.) in both directions.

Cut out along the outer dotted lines. 2.

3.

Optional: Attach to a more rigid surface such as cardboard.
Place the template against the inside of the wheel making sure that the 4. hat/bell surface sits flush against the wheel or, if used, wheel spacers.

At minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

essex parts services, inc. www.essexparts.com

Essex package no. 13.01.10006

DWG. NO. 1313 REV

3