



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

<p>Wheel Clearance Template Porsche 987 Boxter S/Cayman S Rear Radi-CAL Competition Package, 340 mm disc, CP9451 Caliper</p>	<p>essex parts services, inc. www.essexparts.com</p>
<p>Essex package number: 13.01.10055</p>	<p>DWG. NO. 1650 REV</p>