



**Instructions:**

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm [.10 in.] clearance is recommend to account for wheel and suspension component flex.

**Wheel Clearance Template**

Radi-CAL Competition Package  
 Integra Type S, Civic Type R, front  
 CP9660 caliper, 372 mm disc

Essex package no. 13.01.10190  
 13.01.10203

**essex parts  
 services, inc.**  
 www.essexparts.com

DWG. NO. **2251** | REV