



**Instructions:**

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

<p><b>Wheel Clearance Template</b>          Audi RS3 Front          Radi-CAL Competition Package          CP9668 caliper, 372 mm disc</p>	<p><b>essex parts services, inc.</b>          www.essexparts.com</p>
<p>Essex package no. 13.01.10094</p>	<p>DWG. NO. <b>1769</b>   REV</p>