



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. At minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

<p>Wheel Clearance Template BMW E36 and E46 front competition packages</p>	<p>essex parts services, inc. www.essexparts.com</p>
<p>Essex package no. 13.01.10002 (E46) and 13.01.10003 (E36)</p>	<p>DWG. NO. 1294 REV</p>