



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm [.10 in.] clearance is recommended to account for wheel and suspension component flex.

Wheel Clearance Template

BMW E36/E46 M3, E36/46 non-M3, rear packages with 325.4 mm disc

Essex package no. 13.01.10198 (E36 M3),
13.01.10214 (E46 M3), 13.01.10197 (E46 non-M3), 13.01.10222 (E36 non-M3)

**essex parts
services, inc.**
www.essexparts.com

DWG. NO. 2262 REV