



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. At minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

Wheel Clearance Template

BMW E36 M3, E46 M3, E46 non-M3
front packages with 325 mm disc

Essex package no. 13.01.10002 (E46 M3), 13.01.10003 (E36), 13.01.10196 (E46 non-M3)

**essex parts
services, inc.**
www.essexparts.com

DWG. NO. **1294** | REV