



**Instructions:**

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm [.10 in.] clearance is recommend to account for wheel and suspension component flex.

**Wheel Clearance Template**

BMW E36/E46 M3, E46 non-M3, Rear  
CP8350 caliper, 325.4 mm disc

Essex package no. 13.01.10198 (E36 M3), 13.01.10214 (E46 M3), 13.01.10197 (E46 non-M3)

**essex parts services, inc.**

www.essexparts.com

DWG. NO. **2262** REV