



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

<p>Wheel Clearance Template BMW E90 3-Series Rear Radi-CAL Competition Package CP9449 caliper, 340 mm disc</p>	<p>essex parts services, inc. www.essexparts.com</p>
<p>Essex package no: 13.01.10080</p>	<p>DWG. NO. 1725 REV</p>