



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

| | | |
|--|---|-----|
| Wheel Clearance Template BMW E90 front Competition brake package 6 piston caliper, 355 mm disc Essex package no. 13.01.10017 | essex parts services, inc. www.essexparts.com | |
| | DWG. NO. 1422 | REV |