



**Instructions:**

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm [.10 in.] clearance is recommend to account for wheel and suspension component flex.

**Wheel Clearance Template**  
 Radi-CAL Competition Package C8  
 C8 Corvette, Rear  
 CP9661 caliper, 378 mm disc  
 Z06 Essex package no. 13.01.10193  
 Base/Z51 Essex pkg. no. 13.01.10199

**essex parts services, inc.**  
 www.essexparts.com  
 DWG. NO. **2235** | REV