



**Instructions:**

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm [.10 in.] clearance is recommend to account for wheel and suspension component flex.

**Wheel Clearance Template**

Radi-CAL Competition Package  
C8 Corvette, Rear  
CP9669 caliper, 355.6 mm disc

Essex package no. 13.01.10183

**essex parts services, inc.**  
www.essexparts.com

DWG. NO. **2284** | REV