



Instructions:

1. Print out and confirm the scale (150 mm / 5.91in.) in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. At minimum of 2.5 mm (.10 in.) clearance is recommend to account for wheel and suspension component flex.

Wheel Clearance Template

Honda S2000
front competition package

Essex package no. 13.01.10003
13.01.10004

**essex parts
services, inc.**
www.essexparts.com

DWG. NO. 1295 REV

5

4

3

2

1