



Instructions:

1. Print out and confirm the scale in both directions.
2. Cut out along the outer dotted lines.
3. Optional: Attach to a more rigid surface such as cardboard.
4. Place the template against the inside of the wheel making sure that the hat/bell surface sits flush against the wheel or, if used, wheel spacers.
5. A minimum of 2.5 mm [10 in.] clearance is recommend to account for wheel and suspension component flex.

Wheel Clearance Template
Radi-CAL Competition Package
Detroit Speed 9" Ford Rear
CP9449/50/51 Caliper, 340 mm Disc

**essex parts
services, inc.**
www.essexparts.com

Essex package no.: various

DWG. NO. 2052 REV